1/2/3UZ SMOOTH IDLER PULLEY ELATE INSTALLATION



INSTALLATION INSTRUCTIONS

IMPORTANT ** ELATE MFG. RECOMMENDS THAT THIS PRODUCT IS INSTALLED BY A QUALIFIED AUTOMOTIVE MECHANIC OR BY SOMEONE WHO IS MECHANCALLY CONFIDENT IN UNDERTAKING THIS TASK WITH THE EXPECTATION THAT THERE POTENTIALLY COULD BE SCENARIOS THAT ARISE DURING FITMENT THAT MAY NOT BE COVERED BY THESE INSTALLATION INSTRUCTIONS.

ITEMS INCLUDED WITH YOUR KIT:

ITEMS OF NOTE

1 X SMOOTH PULLEY W/ DRESS CAP 1 X M10X45 ZINC BOLT W/ WASHER

BASIC TOOLS REQUIRED LOW OR MEDIUM STRENGTH THREAD SEALANT NEEDED

INSTALLATION STEPS



STEP 1: REMOVE THE DRIVE BELT TO GAIN FULL ACCESS TO THE PULLEY SYSTEM.



STEP 2: USING A 12MM SOCKET REMOVE THE BOLT THAT IS SECURING THE UPPER RIBBED PULLEY TO THE BLOCK.



STEP 3: REMOVE THE PULLEY TO EXPOSE THE STEEL INSERT FITTED TO THE BLOCK..



STEP 4: USING SOME GRIPS CLAMP ONTO THE INSERT AND ROTATE IT BACK AND FORTH. GRADUALLY THE INSERT WILL START TO WORK IT'S WAY FREE FROM THE BLOCK.

1/2/3UZ SMOOTH IDLER PULLEY ELATE INSTALLATION



INSTALLATION INSTRUCTIONS

IMPORTANT ** ELATE MFG. RECOMMENDS THAT THIS PRODUCT IS INSTALLED BY A QUALIFIED AUTOMOTIVE MECHANIC OR BY SOMEONE WHO IS MECHANCALLY CONFIDENT IN UNDERTAKING THIS TASK WITH THE EXPECTATION THAT THERE POTENTIALLY COULD BE SCENARIOS THAT ARISE DURING FITMENT THAT MAY NOT BE COVERED BY THESE INSTALLATION INSTRUCTIONS.

ITEMS INCLUDED WITH YOUR KIT:

ITEMS OF NOTE

1 X SMOOTH PULLEY W/ DRESS CAP 1 X M10X45 ZINC BOLT W/ WASHER

BASIC TOOLS REQUIRED LOW OR MEDIUM STRENGTH THREAD SEALANT NEEDED

INSTALLATION STEPS



STEP 5: WITH THE INSERT REMOVED PLACE THE NEW SMOOTH PULLEY ONTO THE MOUNTING BOSS AND SCREW IN THE SUPPLIED M10 BOLT BY HAND. IT IS ADVISED THAT YOU USE SOME LOW / MEDIUM STRENGTH THREAD LOCKER ON THE NEW BOLT.



STEP 6: USING A RING SPANNER FIRMLY NIP UP THE BOLT. DO NOT OVERTIGHTEN OR YOU RISK STRIPPING THE THREADS OUT OF THE BLOCK.



STEP 7: WITH THE PULLEY NOW FULLEY INSTALLED CLIP ON THE DRESS CAP.